

LUTCHTEC TSB-202


CRANK


1 HAKKINEN RD WINGFIELD SA PH: +618 8300 5000 FAX: +618 8300 5050

BEARING CHECKING GUIDE

RACING CLUTCH RELEASE


MEASURE:











ROOM FOR CLUTCH WEAR = B-A= CLUTCH RELEASE TRAVEL = A-C =≥8mm≥ 4mm

Please provide photos of the inside of the bellhousing, back of motor and any existing clutch components



youtube.com/watch?v=iUG2eggTVNE





Scan with a QR app on your smart phone